


DH-5-6 Humanoid Hand

User Manual



Version:1.01.07

1 Foreword

This manual introduces the specifications, interface definitions, and communication instructions for the 5-finger dexterous hand, helping customers understand and use it.

- 1). Write control variables/read feedback values, access the dexterous hand's register variables (zero initialization, speed, position, and force), and control the dexterous hand to complete specified actions. Read feedback values (speed, position, and current) to understand the dexterous hand's operating status.
- 2). **Preset Action Function:** Customize actions and send them to the dexterous hand for execution.
- 3). **Built-in Gesture Function:** Circularly display preset gestures, supporting the selection/deselection of individual gestures.
- 4). **Historical Fault Alarm Recording Function:** The dexterous hand can store recent faults and can clear all stored faults with one click.
- 5). Supports online upgrades using a host computer.

Target Audience

This manual is intended for:

Customer Engineers

Sales Engineers

Installation and Commissioning Engineers

Technical Support Engineers

1.1 Revision

Version	Date	Revised content
V1.01.02	2024.12.06	Add registers for Modbus configuration
V1.01.03	2025.01.06	<ul style="list-style-type: none"> ● The open-loop force setting range is 20 ~100. Closed-loop force control is not supported. ● Current is in mA, with a range of -32768 to 32767.
V1.01.04	2025.02.18	<ul style="list-style-type: none"> ● Added instructions for using the burn-in test command. Refer to Section 2.5.3. ● Updated the Modbus data frame example. ● Deleted the host computer instructions. For details, see the new host computer instructions.
V1.01.05	2025.04.08	<ul style="list-style-type: none"> ● Updated wiring schematic, refer to section 1.3
V1.01.06	2025.04.25	<ul style="list-style-type: none"> ● Added a communication wiring diagram. ● Updated notes.
V1.01.07	2025.04.30	<ul style="list-style-type: none"> ● Update content layout and add interface description

1.2 Indicator

The indicator light on the palm reflects the current status of the Dexterous Hand.

Blue light: Indicates normal power-on operation.

Red light: Indicates IAP upgrade status, requiring a host computer to upgrade the Dexterous Hand.

1.3 Axis Correspondence

Table 1-1 below shows the correspondence between axis numbers and finger degrees of freedom.

Axis Number	Right Hand	Left Hand
01	Move your thumb left and right	Move your thumb left and right
02	Forefinger	Forefinger
03	Middle finger	Middle finger
04	Ring finger	Ring finger
05	Little finger	Little finger
06	Move your thumb up and down	Move your thumb up and down

Table 1-1 Axis correspondence

2 Content

Content	
1 Foreword	1
1.1 Revision	2
1.2 Indicator	2
1.3 Axis Correspondence	2
2 Content	3
3 Safe Information	4
3.1 Usage Instructions	4
3.2 Precautions	4
3.3 Disclaimer	5
4 Product Introduction	5
4.1 Product Features	5
4.2 Product Advantages	6
4.3 Model Description	6
4.4 Specifications	7
4.5 Structural Dimensions	8
5 Interface Description	9
5.1 External Board Aviation Plug Interface	9
5.2 External Board End Aviation Plug Interface Line Definition	9
5.3 Internal Green Terminal Interface	10
5.4 USB to RS485 Converter interface	10
6 RS485 Communication	11
6.1 RS485 Default Configuration	11
6.2 MODBUS-RTU Protocol Description	11
6.2.1 Function Code 0x03 Read Single/Multiple Holding Registers	11
6.2.2 Function Code 0x06 Write Single Holding Register	12
6.2.3 Function Code 0x06 Write Multiple Holding Register	12
6.3 Custom Protocol Description	13
6.3.1 0x6A Write Single/Multiple Parameters	14
6.3.2 0x69 Read Single/Multiple Parameters	14
6.4 Register Configuration Table	14
6.4.1 Modbus Communication Parameter Configuration (0x03xx)	14
6.4.2 Parameter Setting (0x01xx)	16
6.4.3 Parameter Feedback (0x02xx)	20
6.4.4 System setting parameters (0x05xx)	23
7 Instructions for use of the host computer	25
7.1 Debugging Software Installation and Wiring	25
7.2 Debugging Software Installation and Use	25
8 Error Code	26
9 Notes	27

3 Safe Information

3.1 Usage Instructions

Scope of Application: This 5-Finger Dexterous Hand with 6 Degrees of Freedom (6DOF) is primarily intended for use in scientific research, assisting with specific industrial production processes, and in certain medical rehabilitation training simulation scenarios (under the guidance of professional medical personnel). Dangerous, illegal, or inappropriate uses beyond the product's design are strictly prohibited.

Installation and Connection: Before installing the product, carefully read the included installation instructions. Ensure the installation environment is stable, dry, and free from strong electromagnetic interference. When connecting the product, ensure that all wires are correctly connected according to the connector markings to avoid short circuits or device damage caused by incorrect connections. After completing the connection, perform a preliminary wiring inspection to confirm that there are no loose connections or damage.

Operational Procedure: During operation, strictly follow the action sequence and command input method specified in the operating manual. Avoid violent manipulation or forcibly changing the direction of finger movement while the device is running to avoid damage to the mechanical structure and drive system. During operation, pay close attention to the device's status indicators and feedback data, and immediately cease operation if any abnormalities occur.

3.2 Precautions

Safety precautions: During product operation, do not place any part of your body near moving finger joints or transmission components to prevent pinching or scratching. Operators must wear appropriate protective equipment, such as protective gloves and goggles. If the product is used in an industrial environment, prominent safety warning signs should be posted around the product to prevent unauthorized personnel from approaching.

Environmental requirements: The product should be used within the specified temperature and humidity ranges, generally between [X]°C and [X]°C, and between [X]% and [X]%. Avoid use in environments with high temperatures, high humidity, excessive dust, or corrosive gases to prevent degradation of product performance and lifespan. Also, keep the product away from strong magnetic and electric fields to prevent interference with the product's control system.

Maintenance: Clean the product regularly. Wipe the exterior and exposed parts with a

clean, soft, damp cloth. Avoid using corrosive cleaning agents. Lubricate and maintain the mechanical joints at the intervals specified in the product manual to ensure smooth movement. Regularly check all connections for looseness and cables for damage. Repair or replace any problems promptly. Before performing maintenance, be sure to cut off the power supply of the equipment to prevent accidental startup.

3.3 Disclaimer

User Responsibility: Our company assumes no responsibility for any product damage, personal injury, or other losses caused by failure to follow the instructions and precautions in this safety information, such as unauthorized disassembly or modification of the product, use in an inappropriate environment, or improper operation.

Force Majeure: Our company assumes no responsibility for product failure or damage caused by force majeure, such as natural disasters, war, or government actions. However, we will do our best to assist users in restoring product operation or providing necessary support after the force majeure event has passed.

Third-Party Liability: Our company assumes no responsibility for product failure or damage caused by incompatibility between software, hardware, or services provided by a third party, or improper interference with the product. Users should contact the relevant third party to resolve the issue.

Please carefully read and understand the above safety information before using this *5-Finger Dexterous Hand 6-DOF* product to ensure correct and safe use. If you have any questions, please feel free to contact our customer service team.

4 Product Introduction

4.1 Product Features


- Over a million cycles of service life
- Bulk delivery, quality assurance
- Optional multi-array high-sensitivity tactile sensor
- Inner grip cushioning protection
- Core three-finger pointing function for stable grip of spherical objects

4.2 Product Advantages

- Industrial-grade core components
- Multimodal sensing fusion
- Highly responsive control
- Modular joint design
- API calls for easy linkage
- Scenario-specific customization

4.3 Model Description

■ Selection Method



4.4 Specifications

Technical Specifications	
Degrees of Freedom (DOF)	11
Actuated DOF	6
Cycle Time	0.8s
Finger Bending Angle (4 fingers)	83°+87°
Thumb Bending Angle	38°+7°
Thumb Abduction Angle	85°
Tip Force per Finger	30N
Recommended Maximum Friction Load	2kg
Recommended maximum structural pull load	4kg
Five Fingers Total Gripping Force	30N
Lifting Load Capacity	10kg
Weight	760g
Sensor	Multi tactile sensation (optional function)
Safe Function	Inner grip direction anti-collision buffer
Transmission Mechanism	Hollow cup motor+ planetary gearbox+ lead screw + linkage


Communication Protocols

Modbus-RTU/(RS485)/CAN

Working Voltage


24 V DC ± 10%

4.5 Structural Dimensions




5 Interface Description

5.1 External Board Aviation Plug Interface

Interface Type	PIN	Pin Definition	Interface Diagram
RS485/CAN	1	24Vdc	 Pin 位分布(前视图) M8 母头 A-Coding 4PIN
	2	GND	
	3	RS485A/CANH	
	4	RS485B/CANL	

Pin Assignment (Front View)
 M8 Female Connector, A Coding 4 Pins


5.2 External Board End Aviation Plug Interface Line Definition



5.3 Internal Green Terminal Interface

Interface Type	PIN	Pin Definition	Interface Diagram
RS485/CAN	1	RS485B/CANL	
	2	RS485A/CANH	
	3	GND	
	4	24Vdc	

5.4 USB to RS485 Converter interface

DB9 Pin	Output signal	RS_422 full-duplex wiring	RS_485 half-duplex wiring	DB9针型
1	T/R+	Send(A+)	RS-485(A+)	
2	T/R-	Send(B-)	RS-485(B-)	
3	RXD+	Receive(A+)	N/A	
4	RXD-	Receive(B-)	N/A	
5	SGND	Signal Ground	Signal Ground	
6	N/A	N/A	N/A	
7	N/A	N/A	N/A	
8	N/A	N/A	N/A	
9	N/A	N/A	N/A	



6 RS485 Communication

The communication of the dexterous hand supports MODBUS-RTU protocol and custom protocol. The dexterous hand adopts custom protocol and is debugged and upgraded with the host computer software.

6.1 RS485 Default Configuration

Baud Rate: 115200

Data Bits: 8

Stop Bits: 1

Parity: None

The configuration can be modified through the host computer.

6.2 MODBUS-RTU Protocol Description

The MODBUS-RTU protocol supports function codes 0x03 - read single/multiple holding registers, 0x06 - write single holding register, and 0x10 - write multiple holding registers.

6.2.1 Function Code 0x03 Read Single/Multiple Holding Registers

The format is as follows:

Request:

Address Code	Function Code	Register Starting Address	Number of Registers	CRC Parity Code
1 byte	1 byte	2 byte	N(1~255) byte	2 byte

Table 2-1 0x03 Function Code Request Data Frame Format

Address Code: Indicates the dexterous hand ID. The default right hand ID is 01.

Function Code: 0x03 Reads a single or multiple registers.

Register Start Address: The address at which registers are read.

Number of Registers: The number of registers to be read consecutively (N). Range: 1 to 255.

CRC: CRC checks use a 16-bit cyclic redundancy check.

Response:

Address Code	Function Code	Number of bytes	Register value	CRC Parity Code
1 byte	1 byte	1 byte	2^*N byte	2 byte

Table 2-2 Function Code Response Data Frame Format

Address Code: Indicates the dexterous hand ID. The default right hand ID is 01.

Function Code: 0x03 Reads a single or multiple registers.

Byte Count: The number of bytes in the returned register value.

Register Value: The value of N consecutive registers read. Range: 1 to 255.

CRC: CRC check uses a 16-bit cyclic redundancy check.

6.2.2 Function Code 0x06 Write Single Holding Register

The format is as follows, the request and response formats are consistent

Address Code	Function Code	Register Address	Register value	CRC Parity Code
1 byte	1 byte	2 byte	2 byte	2 byte

Table 2-3 0x06 Request and Response Data Frame Format.

Address Code: Indicates the dexterous hand ID. The default right hand ID is 01.

Function Code: 0x06 Write Single Register.

Register Address: The register address to be written.

Register Value: The value in the register to be written.

CRC: CRC checksum uses a 16-bit cyclic redundancy check.

6.2.3 Function Code 0x06 Write Multiple Holding Register

Request:

Address Code	Function Code	Register Starting Address	Number of Registers	Number of bytes	Register value	CRC Parity Code
1 byte	1 byte	2 byte	2 byte	1 byte	N^*2	2 byte

Table 2-4 0x10 Function Code Request Data Frame Format

Address Code: Indicates the dexterous hand ID. The default right hand ID is 01.

Function Code: 0x10 Write Multiple Registers.

Register Address: The register address to be written.

Register Data: The number of registers to be written consecutively, ranging from 1 to 255.

Byte Count: The number of bytes in the register value to be written.

Register Value: The value in the register to be written.

CRC: CRC checksum uses a 16-bit cyclic redundancy method.

Response:

Address Code	Function Code	Register Address	Register value	CRC Parity Code
1 byte	1 byte	2 byte	2 byte	2 byte

Table 2-5 Response Data Frame Format for Function Code 0x10

Address Code: Indicates the dexterous hand ID. The default right hand ID is 01.

Function Code: 0x10 Write Multiple Registers.

Register Address: The register address to be written.

Register Data: The number of consecutive registers to be written, ranging from 1 to 255.

CRC: CRC check uses a 16-bit cyclic redundancy check.

6.3 Custom Protocol Description

The function codes supported by the custom protocol are 0x69 and 0x6A. The protocol format is shown in Table 2-6 below:

Address Code	Data frame length (including CRC)	Function Code	Data length	Data	CRC Parity Code
1 byte	2 byte	1 byte	2 byte	N byte	2 byte

Table 2-6 Communication Protocol Frame

Address Code: Indicates the dexterous hand's ID. The default ID for the right hand is 01.

Data Frame Length: Contains the byte length from the address code to the CRC check.

Function Code: Describes read and write operations for the dexterous hand. Currently supported are (0x69: read single/multiple registers; 0x6A: write single/multiple registers).

Data Length: Contains the data length (N bytes) and the data length (2 bytes).

CRC: The CRC check uses a 16-bit circular redundancy check.

6.3.1 0x6A Write Single/Multiple Parameters

Function Code	Len	Data					Illustrate
0x6A	2byte	1byte Number of parameters	2bytes Parameter Index	2bytes Parameter value	Nth 2-byte parameter index	Nth 2-byte parameter value	Write parameter value
0x6A	2byte	1bytes ACK (0xFF indicates success, 0xCC indicates a data frame error.)					Response

Table 2-7 0x6A Function Code Data Frame Format

6.3.2 0x69 Read Single/Multiple Parameters

Function	Len	Data		Illustrate
0x69	2byte	1bytes Number of parameters	N*2byteParameter Index	Read parameter value
0x69	2byte	1bytes Number of parameters	N*2byteParameter Index	Response

Table 2-8 0x69 Function Code Data Frame Format

6.4 Register Configuration Table

6.4.1 Modbus Communication Parameter Configuration (0x03xx)

Function Code	Modbus Address	Illustrate	Write	Read
Parameters Save	0x0300	Parameters are stored and automatically loaded at the next power-on. Write 1, and after storage is completed, it will be restored to 0 and take effect after restart.	Parameter range [0-3] 0: Default parameters. 1: Save currently modified parameters. 2: Restore parameters to default values. 3: Save automated test parameters.	Default value: 0
Modbus ID	0x0302	Slave address, takes effect after restart.	Range: 0x01~0xFE	Current value
Baud Rate	0x0303	The baud rate setting of the serial port takes effect after restart.	0-6: 921600, 115200, 57600, 38400, 19200, 9600, 4800 (1:Default)	Current value
Stop Bits	0x0304	Serial port stop bit setting	0:1 Stop bits; 1:2Stop bits (0:Default)	Current value

Parity Code	0x0305	The parity bit setting of the serial port takes effect after restart.	0:No parity; 1:Odd parity; 2:Even parity (0:Default)	Current value
-------------	--------	---	---	---------------

Example:

Set baud rate:

Send: 01 06 0303 0001 B84E

Return: 01 06 0303 0001 B84E

Save parameters:

Send: 01 06 0300 0001 484E

Return: 01 06 0300 0001 484E

6.4.2 Parameter Setting (0x01xx)

Function	Modbus Address	Description	Write	Read
Return to zero	0x0100	Return to origin		
1-axis target position	0x0101	1 axis moves to the specified position	0~65535, Unit 0.01mm	Read the current specified position
2-axis target position	0x0102	2 axis moves to the specified position	0~65535, Unit 0.01mm	Read the current specified position
3-axis target position	0x0103	3 axis moves to the specified position	0~65535, Unit 0.01mm	Read the current specified position
4-axis target position	0x0104	4 axis moves to the specified position	0~65535, Unit 0.01mm	Read the current specified position
5-axis target position	0x0105	5 axis moves to the specified position	0~65535, Unit 0.01mm	Read the current specified position
6-axis target position	0x0106	6 axis moves to the specified position	0~65535, Unit 0.01mm	Read the current specified position
1-axis force	0x0107	Under open-loop force control, the output force of the pushing section is set as a percentage of the rated current;	Open-loop force control: 20~100, %	Read the current percentage of the push section currently set
2-axis force	0x0108	Under open-loop force control, the output force of the pushing section is set as a percentage of the rated current;	Open-loop force control: 20~100, %	Read the current percentage of the push section currently set
3-axis force	0x0109	Under open-loop force control, the output force of the pushing section is set as a percentage of the rated current;	Open-loop force control: 20~100, %	Read the current percentage of the push section currently set
4-axis force	0x010A	Under open-loop force control, the output force of the pushing section is set as a percentage of the rated current;	Open-loop force control: 20~100, %	Read the current percentage of the push section currently set
5-axis force	0x010B	Under open-loop force control, the output force of the pushing section is set as a percentage of the rated current;	Open-loop force control: 20~100, %	Read the current percentage of the push section currently set
6-axis force	0x010C	Under open-loop force control, the output force of the pushing section is set as a percentage of the rated current;	Open-loop force control: 20~100, %	Read the current percentage of the push section currently set

1-axis speed	0x010D	Maximum speed of the motion segment	1~100, %	Read current setting
2-axis speed	0x010E	Maximum speed of the motion segment	1~100, %	Read current setting
3-axis speed	0x010F	Maximum speed of the motion segment	1~100, %	Read current setting
4-axis speed	0x0110	Maximum speed of the motion segment	1~100, %	Read current setting
5-axis speed	0x0111	Maximum speed of the motion segment	1~100, %	Read current setting
6-axis speed	0x0112	Maximum speed of the motion segment	1~100, %	Read current setting
1-Axis Acceleration/Deceleration	0x0113	Acceleration and deceleration of motion segments	1~100, %	Read current setting
2-Axis Acceleration/Deceleration	0x0114	Acceleration and deceleration of motion segments	1~100, %	Read current setting
3-Axis Acceleration/Deceleration	0x0115	Acceleration and deceleration of motion segments	1~100, %	Read current setting
4-Axis Acceleration/Deceleration	0x0116	Acceleration and deceleration of motion segments	1~100, %	Read current setting
5-Axis Acceleration/Deceleration	0x0117	Acceleration and deceleration of motion segments	1~100, %	Read current setting
6-Axis Acceleration/Deceleration	0x0118	Acceleration and deceleration of motion segments	1~100, %	Read current setting

Table 2-9 Setting Parameters

Initialization Home Return (0x0100): **Initialization home return is required after each power cycle.**

As shown in Table 2-9, the home return method is described using two bytes, with each axis corresponding to two bits.

Axes 1-6: 01: Closed;

10: Open;

11: Find total travel;

00: Do not perform home return on the current axis.

Rese rve	Rese rve	Rese rve	Rese rve	Axis 6		Axis 5		Axis 4		Axis 3		Axis 2		Axis 1	
Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0

Table 2-10 Definition of return to zero format

Example: (right hand)

Set open home position:

Send: 01 06 0100 0AAA 0e e9

Return: 01 06 0100 0AAA 0e e9

Set closed home position:

Send: 01 06 0100 0555 4b 59

Return: 01 06 0100 0555 4b 59

Set the positions of axes 1 through 6 to all 0:

Send: 01 10 0101 0006 0C 0000 0000 0000 0000 0000 0000 9a d7

Return: 01 10 01 01 0006 1037

Set the positions of axes 1 through 6 to 400, 900, 900, 900, 900, and 400, respectively:

Send: 01 10 0101 0006 0C 0190 0384 0384 0384 0304 0190 0cbc

Return: 01 10 01 01 0006 1037

Set the speed of axes 1 through 6 to 100%:

Send: 01 10 010d 0006 0C 0064 0064 0064 0064 0064 fa1b

Return: 01 10 010d 0006 d034

Set the pushing force of axes 1 through 6 to 100%

Send: 01 10 0107 0006 C0 0064 0064 0064 0064 0064 7cbc

Return: 01 10 0107 0006 f036

Set the position, force, and speed of axis 1: // Position 1mm, force 100%, speed 100%.

Sent: 01 000D 6A 000d 03 0101 0064 0107 0064 010D 0064 69A7

Return: 01 0009 6A 0001 FF 8BC9

Set the position, force, and speed of axis 2: // Position 5 mm, force 100%, speed 100%

Sent: 01 0015 6a 000d 03 0102 01F4 0108 0064 010E 0064 C1 A5

Return: 01 0009 6A 0001 FF 8BC9

Set the position, force, and speed of axis 3: // Position 9.5 mm, force 100%, speed 100%

Sent: 01 0015 6a 000d 03 0103 03B6 0109 0064 010F 0064 A532

Return: 01 0009 6A 0001 FF 8BC9

Set the position, force, and speed of axis 4: // Position 5 mm, force 100%, speed 100%

Sent: 01 0015 6a 000d 03 0104 01F4 010A 0064 0110 0064 34E9

Return: 01 0009 6A 0001 FF 8BC9

Set the position, force, and speed of axis 5: // Position 9.5 mm, force 100%, speed 100%

Sent: 01 0015 6a 000d 03 0105 01F4 010B 0064 0111 0064 7115

Return: 01 0009 6A 0001 FF 8BC9

Set the position, force, and speed of axis 6: // Position 9.5 mm, 100% force, 100% speed

Sent: 01 0015 6a 000d 03 0106 0000 010C 0064 0112 0064 F891

Returned: 01 0009 6A 0001 FF 8BC9

6.4.3 Parameter Feedback (0x02xx)

Function	Modbus Address (hexadecimal)	Description	Read
Return to zero state	0x0200	Feedback of current origin status	Read the current return to zero status
Axis 1 operating status	0x0201	Feedback on the current motion status of axis 1 (including fault code, the fault code is 0 if it is in place normally)	0:Moving, 1: Reached position; 2: Stalled
Axis 2 operating status	0x0202	Feedback on the current motion status of axis 2 (including fault code, the fault code is 0 if it is in place normally)	0: Moving, 1: Reached position; 2: Stalled
Axis 3 operating status	0x0203	Feedback on the current motion status of the 3-axis (including fault codes, the fault code for normal operation is 0)	0: Moving, 1: Reached position; 2: Stalled
Axis 4 operating status	0x0204	Feedback of the current motion status of the 4 axes (including fault codes, the fault code for normal operation is 0)	0: Moving, 1: Reached position; 2: Stalled
Axis 5 operating status	0x0205	Feedback of the current motion status of the 5-axis (including fault code, the fault code is 0 if it is in place normally)	0: Moving, 1: Reached position; 2: Stalled
Axis 6 operating status	0x0206	Feedback of the current motion status of the 6 axes (including fault codes, the fault code for normal operation is 0)	0: Moving, 1: Reached position; 2: Stalled
Axis 1 current position	0x0207	Feedback of the current position of axis 1	Read current position
Axis 2 current position	0x0208	Feedback of the current position of axis 2	Read current position
Axis 3 current position	0x0209	Feedback of the current position of axis 3	Read current position
Axis 4 current position	0x020A	Feedback of the current position of axis 4	Read current position
Axis 5 current position	0x020B	Feedback of the current position of axis 5	Read current position
Axis 6 current position	0x020C	Feedback of the current position of axis 6	Read current position
Axis 1 speed information	0x020D	Feedback of the current speed	Read current speed
Axis 2 speed information	0x020E	Feedback of the current speed	Read current speed
Axis 3 speed information	0x020F	Feedback of the current speed	Read current speed

Axis 4 speed information	0x0210	Feedback of the current speed	Read current speed
Axis 5 speed information	0x0211	Feedback of the current speed	Read current speed
Axis 6 speed information	0x0212	Feedback of the current speed	Read current speed
Axis 1 current	0x0213	Feedback axis 1 current. Unit: mA, range: -32768 to 32767	Read current current
Axis 2 current	0x0214	Feedback axis 2 current. Unit: mA, range: -32768 to 32767	Read current current
Axis 3 current	0x0215	Feedback axis 3 current. Unit: mA, range: -32768 to 32767	Read current current
Axis 4 current	0x0216	Feedback axis 4 current. Unit: mA, range: -32768 to 32767	Read current current
Axis 5 current	0x0217	Feedback axis 5 current. Unit: mA, range: -32768 to 32767	Read current current
Axis 6 current	0x0218	Feedback axis 6 current. Unit: mA, range: -32768 to 32767	Read current current

Table 2-11 Feedback parameters

Return to zero status (0x0200), the numerical correspondence is as follows:

Axes 1-6: 0: Uninitialized 00;

1: Initialized successfully 01;

2: Initializing 10

Reserve	Reserve	Reserve	Reserve	Axis 6		Axis 5		Axis 4		Axis 3		Axis 2		Axis 1	
Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0

Table 2-12 Definition of zero return feedback format

Example:

Query the return-to-zero status:

Send: 01 000B 69 0003 01 0000 E51D

Return: 01 000B 69 0003 01 AAAA 1BC2

Query the feedback data from 0x0201 to 0x0217:

Send: 01 00 2B 69 00 25 11 02 01 02 02 03 02 04 02 05 02 06 02 07 02 08 02 09 02 0A 02
0B 02 0C 02 13 02 14 02 15 02 16 02 17 B2 63

Return: 01 00 2B 69 00 23 11 00 01 00 01 00 01 00 01 00 01 00 01 02 13 01 F4 03 B6 01 F4
01 F4 00 13 00 03 00 0A FF F7 00 00 A9 C7

6.4.4 System setting parameters (0x05xx)

Function	Modbus Address (hexadecimal)	Description	Write	Read
Clear current error	0x0501	Clear currently displayed errors	The parameter range is [0,1]. The default value is 0. Writing a value of 1 clears the current error.	Clear successfully reads the default value 0.
System restart	0x0503	Restart the software system	The parameter range is [0,1]. The default value is 0. Writing 1 will restart the software.	Reads as the default value 0.
Aging test	0x0504	Configure this variable and the aging test will be automatically performed after power-on.	The parameter range is [0,1]. The default value is 0. If you write 1, the system will automatically initialize and perform the opening and closing reciprocating motion.	Reads as the default value 0.

Note: The aging test function needs to remain effective after power off and restart. You need to write 3 to the 0x0300 register to save the current register value.

Example:

Clear errors:

Send: 01 06 0501 0001 1906

Return: 01 06 0501 0001 1906

System restart:

Send: 01 06 0503 0001 b8c6

Return: 01 06 0503 0001 b8c6

Open aging test:

Send: 01 06 0504 0001 0907

Return: 01 06 0504 0001 0907

Turn off aging test

Send: 0106 0504 0000 c8c7

Return: 0106 0504 0000 c8c7

(If power off and restart are required, store the flag of the aging test and send the following data frame to save the parameters.)

Send: 01 06 0300 0003 c98f

Return: 01 06 0300 0003 c98f

7 Instructions for use of the host computer

7.1 Debugging Software Installation and Wiring

Connect via debugging software, essentially controlling the device via the RS485 interface.

The wiring requires four wires: 24V, GND, 485_A (T/R+, 485+), and 485_B (T/R-, 485-). Power is provided by a 24V DC regulated power supply. Plug the 485's USB port into a computer's USB port. The wiring is as follows:

485A connects to the T/R+ terminal of the 485-to-USB module;

485B connects to the T/R- terminal of the 485-to-USB module;

24V connects to the positive terminal of the 24V DC regulated power supply;

GND connects to the negative terminal of the 24V DC regulated power supply.

DB9 Pin	Output signal	RS_422 full-duplex wiring	RS_485 half-duplex wiring
1	T/R+	Send(A+)	RS-485(A+)
2	T/R-	Send(B-)	RS-485(B-)
3	RXD+	Receive(A+)	N/A
4	RXD-	Receive(B-)	N/A
5	SGND	Signal Ground	Signal Ground
6	N/A	N/A	N/A
7	N/A	N/A	N/A
8	N/A	N/A	N/A
9	N/A	N/A	N/A

DB9針型






Figure 3-1 Wiring Diagram

7.2 Debugging Software Installation and Use

Refer to the host computer user guide. DH5 Control Studio Host Computer User Guide.

8 Error Code

NO	English Explanation	Chinese Explanation	Error Code
1	MOTOR_OFF_MOVE_ERR	Movement command when servo is OFF	0x80
2	HOME_NONE_MOVE_ERR	Position movement command when origin return is not completed	0x82
3	HOME_NONE_CMD_ERR	Numerical command when origin return is not completed	0x83
4	HOMEING_MOVE_ERR	Movement command during home return execution	0x84
5	NO_TABLE_ERR	Abnormal position NO. during movement	0x85
6	PULSE_CMD_ERR	Move command when pulse train input is valid	0x86
7	RESET_ERR	Software reset when servo is ON	0x90
8	TEACH_NO_TABLE_ERR	Position NO. abnormal during teaching	0x91
9	MOCE_PWRT_ERR	PWRT signal detected during movement	0x92
10	HOME_NONE_PWRT_ERR	Homing incomplete status PWRT signal detected	0x93
11	DCLR_ERR	The DCLR signal is detected during the reference position movement command.	0x95
12	POS_DATA_ERR	Parameter data abnormality	0xA1
13	PARM_DATA_ERR	Abnormal location data	0xA2
14	CMD_INF_ERR	Position instruction information data abnormality	0xA3
15	PULSE_CNT_ERR	Instruction counter overflow	0xA4
16	PULSE_ACC_ERR	Command deceleration abnormality	0xA7
17	TYPE_ERR	Incompatible motor and encoder types	0xA8
18	MOTOR_LOCK_ERR	Excitation detection error	0xB8
19	SIGNAL_SNESOR_ERR	Origin sensor not detected	0xBA
20	SIGNAL_HOME_ERR	Origin return timeout	0xBE
21	OVER_SPEED_ERR	Actual speed is too fast	0xC0
22	SERVO_ERR	Servo abnormality	0xC1
23	OCU_ERR	Over current	0xC8
24	OVO_ERR	Over voltage	0xC9
25	OTEM_ERR	Overheat	0xCA
26	AD_OFFSET_ERR	Current sensor offset adjustment abnormality	0xCB
27	CTRLV0_ERR	Abnormal control power supply voltage	0xCC
28	CTRLUNDERV0_ERR	Control power supply voltage is too low	0xCE
29	IO_POWER_ERR	I/O 24V Power supply abnormality	0xCF
30	DIRVE_ERR	Drive source abnormality	0xD4
31	HOME_NONE_POSCNT_ERR	Deviation counter overflows when home	0xD5

		return is not completed	
32	POSCNT_ERR	Deviation Overflow	0xD8
33	POS_OVERLIMIT_ERR	Travel software limit exceeded error	0xD9
34	PUSHPOS_OVERLIMIT_ERR	Pushing range over limit error	0xDC
35	CRASH_ERR	Collision Detection	0xDF
36	OVER_LOAD_ERR	Over load	0xE0
37	ENCODER_ERR	Encoder receiving error	0xE5
38	ENCODER_CNT_ERR	Encoder counting error	0xE6
39	ENCODER_ABPULSE_ERR	Phase A and B are disconnected	0xE8
40	ENCODER_ABS_ERR	Battery-less ABS error	0xEB
41	FLASH_ERR	Non-volatile memory write verification exception	0xF5
42	UVO_ERR	Under voltage	0xF6
43	LOCKED_ROTOR	Stalled	0xF7
44	EMC	STO Emergency Stop	0xF8
45	SET_PARAM_ABNORMAL	Parameter variable exceeds the boundary value	0x20
46	F1_COMMUN_ERROR	Right thumb moves left and right Communication abnormality	0x21
47	F2_COMMUN_ERROR	Right index finger communication abnormality	0x22
48	F3_COMMUN_ERROR	Right middle finger communication abnormality	0x23
49	F4_COMMUN_ERROR	Right ring finger abnormal communication	0x24
50	F5_COMMUN_ERROR	Right hand pinky finger communication abnormality	0x24
51	F6_COMMUN_ERROR	Right thumb moves up and down, communication abnormality	0x26
52	READ_PRAM_ABNORMAL	Abnormal travel parameter reading	0x27
53	OVER_VOLTAGE	Over voltage	0x29
54	UNDER_VOLTAGE	Under voltage	0x30

Table 4-1 Fault Codes

9 Notes

- If the DH5 Smart dexterous hand automatically opens and closes and reciprocates after powering on, it is operating in aging test mode. Refer to the system settings to disable aging test.
- After clearing single-axis errors, reinitialize the axis.
- If a single axis fails to move, rule out communication issues or mechanical stalls.